

MAINTENANCE PROCEDURE

SUPAWOOD Panels are a combination of a medium density fibreboard or a plywood substrate with either a wood veneer, polyurethane paint or our own SUPAFINISH concept veneer applied to the face or edge of the panel.

Occasionally SUPAWOOD panel will require touching up where minor damage occurs on installation or by vandalism. Touch-Up Kits are available on request with every order, and the following methods are recommended for rectification.

CLEANING

Remove marks with a damp cloth and dry thoroughly.

Remove stubborn stains with 'Spray N Wipe' or equivalent and a soft cloth.

Do not use abrasive cleaning chemicals or strong solvents.

If in doubt call us on 1800 002 123 for further advice.

By observing the above basic care guidelines you can expect the finish to look good for years.

REPAIR ON SITE

Timber Finishes

A Timber Touch-Up Kit is available for repairing scratches, nicks, gouges and burns, as follows:

1. Easy-to-use markers – (Darker Timbers only)

For scratches and nicks simply stroke in the direction of the scratch.

For burns, scrapes and worn areas, stroke in the direction of the wood grain.

Wipe off any excess immediately after application with a dry tissue.

2. Easy-to-use Fill-Sticks

For filling in dents and gouges. No heating or pre-mixing needed.

Simply rub in and dab off excess with lint-free cloth or tissue. Avoid rubbing as this can create a glossy area.

Polyurethane Painted Finishes

Carefully follow mixing instructions supplied with the Touch-Up Kit.

Apply the coating sparingly to the immediate area of damage using a fine brush.

Note: The above applies to chips etc no large than 10mm

REPLACEMENT / REPAIR OF PANELS

In the event that the SUPAWOOD panels are damaged beyond what can be repaired using the touch-up kits on-site, a professional touch-up service is available or replacements panels can be purchased.

Technical Document #9200